


Tafel: A

1	inlet manifold
2	screw m 8 x 1,25 x 45
3	gasket
8	gasket
9	exchanger assy 1204-1404 da 02/00 ex 434
10	screw m 8 x 60
11	screw
12	flange ex 083
13	gasket
14	stud m 8 x 20
15	washer diam.8
16	nut
17	complete air filter
18	clamp dia. 60 inox
1	inlet manifold


Tafel A



Tafel: B

1	piston ring set
1	piston ring set
1	piston ring set
2	piston
2	piston assy focs ldw 1104
2	piston
2	piston
2	piston
2	piston
3	brass
4	pin
5	seeger


Tafel B



Tafel: C

1	key
2	shaft
2	crankshaft 1104 m (l.marine)
3	cap
4	tapper pin
5	flywhell
5	6" 1/2 flywheel with crown
5	flywhell
5	flywhell
6	screw
7	screw
8	crown
9	screw


Tafel C



Tafel: D

1	screw
2	nut
3	screw
4	nut
5	rocker arm
5	rocker level
6	support
7	washer
8	nut
9	stud
10	tapper pin
11	cap
12	rocker level
13	rocker level
14	camshaft
15	rocker arm shaft
17	cam
18	screw
19	belt
20	hose
22	o-ring
23	water pump support
25	screw
26	cover
27	o-ring
28	bearing
29	stud
30	plate substituted by r06275.166.0
31	screw m 6 x 10
32	washer
33	support
35	bushing
36	bearing
37	screw
38	washer
39	pulley
40	o-ring
41	nut
42	belt tightening


Tafel: D



Tafel E

1	cap
2	gasket
3	dowel
4	crankcase
5	gasket
6	flange
7	screw
8	bell housing ex 315
8	flanging bell standard
8	short flanging bell mg
9	bolt
10	cap
11	screw m 12
12	dowel
13	ring
13	ring
13	ring
13	ring
13	ring
13	thrust washer +0,20
14	tapper pin
15	seal ring
16	screw
17	
17	
18	mount
18	lower unit, rad. side ldw1204 s-drive
19	bolt m 12 x 28
20	
20	
21	brass
21	brass
21	brass
22	
22	
23	joint
24	sd trasmission
25	washer diam.8

26	bolt
27	elasitc washer diam. 12
28	support
30	sd trasmission
31	mount
32	elasitc washer diam. 12
33	bolt m 12x22
34	lower unit, air filter side ldw1204 s-dr
34	mount
1	cap
2	gasket
3	dowel
4	crankcase
5	gasket
6	flange




Tafel F

1	hose
2	screw
3	gasket
4	nut
5	washer
6	stud
7	feed pump (ex. 097)
8	o-ring
9	drive rod
10	o-ring
11	nut
12	stud
13	washer
14	tapped
16	valve
17	spring
18	valve
20	pumping element
21	nut
21	gasket
22	push-rod support
23	spring
24	tappet
25	injection pump
27	thickness
27	thickness
27	thickness
27	thickness
27	thickness
27	thickness
27	adj.spacer 1,90
27	thickness
27	adj.spacer 1,80
27	thickness
28	spring
29	rod
30	spacer
31	filler

32	gasket
35	o-ring
36	hose
37	screw
38	retainer
39	ring
40	spark arrestor
41	o-ring
43	spray nozzle
44	union bolt
45	gasket
46	gasket
47	fuel pipe between fuel pump-tank.(d9-d7)
48	tube
49	clamp
50	tube
51	gasket
52	gasket
52	union bolt
53	washer diam.10
54	washer diam.10
55	screw
56	support
56	support
57	washer diam.8
58	fuel filter
59	gasket
60	cartridge
61	bolt
62	screw m 10 x 50
63	spacing
64	nut
65	fuel recirculation pipe only mg engines
65	bleed pipe focs (racc.d9-d7)
66	gasket
69	bolt
70	fuel pipe
71	gasket


Tafel F



Tafel G


1	screw
2	belt cover
3	cap
7	screw m 8 x 1,25 x 40
9	fan support
13	gasket
14	gasket
15	
15	
16	
16	
20	screw
21	union
24	
24	
26	screw m 8 x 1,25 x 35
28	
28	
29	screw
30	water pump
31	screw
32	thermostat cover
33	thermostat
34	o-ring
35	thermostat
36	screw
37	screw
44	gasket
45	cap
47	screw
48	thermostat
49	gasket
50	thermostat
51	gasket
52	hose extension x boiler
1	screw
2	belt cover
3	cap
7	screw m 8 x 1,25 x 40

Tafel G



1	
1	
2	plug
3	gasket
4	spring
5	o-ring
5	o-ring
6	
6	
7	gasket
8	pin
9	tapper pin
10	oil dipstick
11	seal ring 32 x 50 x 6
12	drive rod
13	screw
14	screw m 6 x 10
15	rubber oil seal 8,00
16	o-ring
16	o-ring
17	pulley
18	rubber oil seal
19	gasket
20	screw
21	oil pump ass.y
21	oil pump
22	bolt
23	washer
24	hose
25	connector
26	washer
27	screw m 6 x 1 x 12
28	sump
29	gasket
30	screw
31	oil filter cartridge
32	screw
33	gasket
34	washer


36	bolt m 10 x 1,5 x 40
37	m14 portine focs
38	pump
39	clamp
40	tube
41	tube
44	
44	
1	
1	
2	plug
3	gasket
4	spring
5	o-ring
5	o-ring
6	
6	
7	gasket
8	pin
9	tapper pin
10	oil dipstick
11	seal ring 32 x 50 x 6
12	drive rod



Tafel I

1	gasket
2	extra mg
2	extra fuel device
3	stud bolt
4	ext.lever (ex 0052011530)
6	cable end
7	nut
8	bolt
9	connecting rod
9	connecting rod
10	plate
11	plate
12	washer
13	screw
14	spring
14	spring
15	washer
16	plate
16	plate
17	nut m 4
18	plate
20	split pin
21	o-ring
22	spring
22	spring
22	spring
23	o-ring
24	control lever pin
25	screw m 5 x 0,8 x 7
26	tappet
27	lever
28	nut
29	screw
30	spring
31	sleeve
32	internal lever
33	spring lever
34	journal
35	lever
36	o-ring

37	stud m 6 x 10 (19)
38	safety plate
39	spring
40	nut
41	gasket
42	nut
43	bolt
44	nut




Tafel L

1	clamp
2	rocker arm cover
3	tube
4	cap
5	screw
6	brace
8	hose
9	joint
10	hose
11	
11	
12	cap
12	plug diam. 8
13	strip fixing
14	oil transducer
15	gasket
16	
16	
17	spring
18	valve
19	included with table I pos. 2
20	
20	
21	
21	
22	retainer
23	valve guide
23	valve guide +0,50
24	head
25	cap
26	screw
27	washer
28	exhaust valve
29	washer
30	plug d.30
31	cap
33	nut
35	gasket
35	gasket
35	gasket


36	valve seat
37	valve seat
38	valve
41	bolt
42	braket
43	stud bolt
44	washer

Tafel L



1	bolt
2	washer
3	screw
4	nut
5	support
6	glow plug
7	plug wire
8	bolt
9	washer
10	alternator
10	alternator
11	nut
12	starter


Tafel M



Tafel N


1	gasket set
1	gasket set

N




Tafel P

1	bell for tmc 60 ex 308
1	o-ring
2	washer
3	bolt m 10 x 30
4	joint
6	screw
7	technodrive rev. gear tmc60 1,5:1
7	gear-box
7	gear-box
7	technodrive rev. gear tmc 60 2:1
7	technodrive rev. gear tmc 60 a 2:1
7	technodrive rev. gear tmc 60 2,9:1



2	wiring loom
3	engine speed indicator
4	voltmeter
6	cover
7	switch
8	fuse carrier
9	fuse
10	bell
11	lamp
12	pilot lamp
13	pilot lamp
14	oil window
15	pilot lamp
16	starting switch
21	transducer
22	gasket
23	union
24	gasket
25	lubrication oil pressure sense wye
26	gasket
27	screw
28	gasket
29	transducer
30	fuse
31	fuse box
32	glow plugs control box
33	rele' 12v 20a
34	rtg female connector - 12 poles
35	electric box (not available)
36	rtg male connector -12 poles
37	extention cable - 5 ml
37	cable extention+connector 10 m telve
37	cable extention+connector 15 m telve
44	bell support locking stud 1204t
45	support for wiring
46	washer
47	washer
48	screw
49	socket cap screw m5x16 uni 5931 inox


50	washer d. 5
51	nut
2	wiring loom
3	engine speed indicator
4	voltmeter
6	cover
7	switch
8	fuse carrier
9	fuse
10	bell
11	lamp
12	pilot lamp



Tafel R

1	connector
2	o-ring
2	set of seals for pump jabsco
3	impeller
3	impeller2
4	screw
5	
5	
6	
6	
7	o-ring
8	joint
9	pump
9	water pump jota
10	block
10	block
12	gasket
14	connector
16	gasket for riser focs (ex 0045010980)
17	riser
18	stud bolt
19	washer
20	nut
21	gasket
22	cap
23	spring washer 8 din 137b inox
24	
24	
25	clamp
26	tube
27	exchanger assy 1204-1404 da 02/00 ex 434
28	tube
29	clamp
31	
31	
32	sealing oring
33	tube
36	screw
37	
37	


38	screw
39	tube
40	clamp
41	
41	
42	clamp
45	sealing oring
46	cap
49	screw
50	clamp
51	tube
53	screw
56	gasket
57	plug for exchanger 1/8" gas
60	cap
61	
61	
62	nipple
63	plug
64	
64	



Tafel S

1

engine block



ATTENZIONE: LO SHORT BLOCK E' COMPOSTO DA BASAMENTO, ALBERO MOTORE, BIELLE E PISTONI GIA' PREMONTATI

ATTENTION: THE SHORT BLOCK IS BUILT-UP BY CRANK-CASE, CRANK-SHAFT, CONNECTING RODS AND PISTONS ALREADY ASSEMBLED.